

# OPERATING & SAFETY GUIDE

## COMMERCIAL MICROWAVE

### GENERAL SAFETY

Contact Event Furniture Limited for information and advice on the suitability and safety of this type of equipment.

There is a risk of injury if you do not follow the instructions printed in this guide.

This equipment should only be used by a competent adult who has read and understood these instructions. Anyone with a temporary or permanent disability should seek expert advice before using the equipment.

Keep all children, animals and bystanders away from the work area. Ensure the floor of the work area is free from trip hazards and non-slip. Never use the equipment if you are ill, tired or under the influence of alcohol or drugs.

Never operate electrical switches with wet hands. Always switch off and unplug the equipment from the power supply before moving or cleaning.

Check the equipment before use, if it shows signs of damage request a replacement.

### ELECTRICAL SAFETY

The equipment is designed to plug directly into a standard 240volt, 13 amp socket. Make sure the equipment and power socket are switched off before plugging into the power supply. If the equipment fails to operate or the power cable or plug become damaged, contact Event Furniture Limited. Do not try to repair it yourself.

Keep the power cable out of harm's way. Extension leads should be unwound fully, never run them through water, over sharp objects or where they may be a trip hazard.

Use a suitable RCD (Residual Current Operated Device) to reduce the risk of electric shock.

### OPERATING GUIDE

Position the unit where it is to be used and ensure that it is level and away from heat sources such as radiators or fires and also, away from extreme cold. Allow at least 10cms of space all around the oven and 30cms above to allow warm air to escape via the vents during cooking.

- Plug the oven into a 13 amp electrical socket, the digital display will show "0".
- You can input the buttons and timer control only when the door is closed.
- Oven lamp and fan motor work for 1 minute whenever the door is opened or after cooking.
- The programme is cancelled when any button or timer control are not pressed for more than 3 minutes during programming.
- To cancel the programme during cooking, open and close the door twice.
- "End" will appear on the display after the time reaches zero. It will disappear when the oven door is opened.

### OPERATING GUIDE cont'd

**Note:** Outer areas of food are heated by microwave energy and remaining portions by conduction. It is, therefore, important to turn, re-arrange or stir food to ensure even heating. Where recommended, allow food to stand, this is not optional but necessary to ensure thorough cooking and is particularly important for dense food such as joints of meat.

Metallic dishes are not suitable for microwaving.

#### **Manual Cooking:**

The oven can be programmed up to 30 minutes and has 4 preset power levels.

Levels	Power	Wattage
High	100%	1900
Medium	50%	950
Med Low	20%	380
Low	10%	190

The input unit of cooking (defrosting) time varies from 2 to 30 seconds. It depends on the length of the cooking (defrosting) time as shown on the table below.

Cooking Time	Increased Unit
0-60 seconds	2 seconds
1-3 minutes	5 seconds
3-10 minutes	10 seconds
10-30 minutes	30 seconds

It is not necessary to touch the power level button for 100%.

During cooking mode the oven stops when the door is opened and the programme is cancelled if any buttons or timer control are not touched within 1 minute after the door is opened.

The remaining cooking time is cancelled when the door is closed and opened during stop mode.

If the control is rotated counter-clockwise, the cooking time will decrease from 30 minutes by degrees.

#### **TIME COOK**

Example: If you want to cook for 2 minutes and 30 seconds at MEDIUM.

##### STEP 1

Enter cooking time by rotating the TIME CONTROL to show "2 min. 30sec".

##### STEP 2

Select power level by pressing the POWER LEVEL button to "MEDIUM"

##### STEP 3

Press START button once to start cooking, the display will start to count down to zero.

### OPERATING GUIDE cont'd

#### **DEFROST**

You can defrost food by using the DEFROST button.

Example: To defrost 450g (1lb) beef joint for 10 minutes.

##### **STEP 1**

Enter the defrost time using the TIME CONTROL to show 10min.

##### **STEP 2**

Press the defrost button.

##### **STEP 3**

Press START button once to start defrosting, the display will start to count down to zero. Turn over 4-5 times during defrosting.

Allow food to stand a few minutes after defrosting. Check food after standing, continue to defrost if additional time is needed.

You can defrost foods by using the MED LOW button.

#### **REPEAT COOK**

The oven can memorise the last cooking time in each power level. If this function is used, there is no need to enter the cooking time.

Example: If you want to use this function at 100%, the last cooking time was 10 minutes.

##### **STEP 1**

Select desired power level (HIGH), check last programme (10 MIN)

##### **STEP 2**

Press START button once to start cooking, the display will start to count down to zero.

#### **CLEANING**

Switch off and unplug the unit.

Do not use sharp objects, metal scrapers, wire brushes or wire wool pads as they can scratch the steel.

Do not use bleach or any corrosive detergent as they will damage the surface of the unit.

Do not allow corrosive foodstuffs such as fruit juices, vinegar, mustards, pickles, etc., to remain on stainless steel for long periods. Wash and rinse away.

After cleaning with a mild detergent, always remove any residue with a damp cloth and wipe dry.